




## HOW TO EXPORT SUPPORT DATA TO A USB KEY


1. The decoder has to be powered on, if not, power on and wait until the initialization is completed.
2. Insert a USB memory stick in the USB slot in front of the decoder, the Memory Stick Menu will appear on the display \*



- 3 Press the acknowledge button  on "Write all passings", the message " Writing passings" and a progress bar will appear on the display \*

- 4 Once the writing is completed, the message "done" appears on the display.



- Press the acknowledge button 


The decoder will return to the standard display information.

- 5 Press the select button  , following menu will appear \*



6 Press the acknowledge button  on “Memory Stick” \*



7 Press the select button  to highlight the menu “ Write support” \*



Press the acknowledge button  on “Write support ”, the message “ Write support” and a progress bar will appear on the display \*

8 Once the writing is completed, the message “done” appears on the display.



Press 

9 Remove the USB memory stick

10 The menu Write all passings generates 2 files: 1 file with a txt extension, another with a p3 extension. The Menu Write support generates 1 file with a p3 extension. Send the 3 files by e-mail to [support@amb-it.com](mailto:support@amb-it.com)

\* Note that if no menu is selected within 10 seconds, the display information on the decoder returns to the default information. See point 5 to return to the menu “Memory Stick”